

Evaluation of PET Plaques for Color, Haze and Inclusions

Document Code – PET-S-09

Publication or Revision Date: November 16, 2018

Introduction – Scope, Significance and Use

Products made with PET are often valued because they have high clarity along with low color and haze. When recycling clear PET, it is important that the PET resin, additives, and any other features employed such as labels or closures have the least possible impact on the color and transparency of the resin. Industry experience is that inks, adhesives, additives, layers and coatings, for example, can be sources of color formation and specks in recycled PET.

This document presents a standard method to evaluate any contribution to color, haze or inclusions that might result from recycling PET articles. The test measures the color and haze values of transparent injection molded plaques. This evaluation is an important part of many APR tests and is used to measure any impact of a design feature such as labels, inks, adhesives or additives on PET recycling.

Disclaimer: *This document has been prepared by the Association of Plastic Recyclers as a service to the plastic industry to promote the most efficient use of the nation's plastic recycling infrastructure and to enhance the quality and quantity of recycled postconsumer plastic. The information in this document is offered without warranty of any kind, either expressed or implied, including WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, which are expressly disclaimed. APR and its members accept no responsibility for any harm or damages arising from the use of or reliance upon this information by any party. Participation in the Recognition Program is purely voluntary and does not guarantee compliance with any U.S. law or regulation or that a package or plastic article incorporating the innovation is recyclable or will be recycled.*

Reference Documents

APR Practice “Injection Molding 3 mm PET Plaques”, PET-P-08

Test Method Summary

3 mm thickness injection molded - amorphous and transparent - PET plaques are prepared. Plaques are evaluated for d65 CIE L*a*b* color values and haze using a color spectrophotometer in transmittance mode. Plaques are evaluated visually for any presence of black specs or other inclusions.

Equipment Required

- Color spectrophotometer capable of measuring CIE L*a*b* Scale and Haze % in transmittance mode with d65 light source.
- Diffuse white light source to use in visual inspection for black specks and inclusions.

Materials Required

- Injection molded plaques 3 mm thick of control and test PET articles.
- TAPPI Calibrated Size Estimation Chart, or Ryan Quality Control provides an alternate size standard chart showing defects with size 1 mm²
- As alternative to the size chart, a measurement tool capable of evaluating black specks and inclusions greater than 0.35 mm in the largest dimension. (A circle with diameter of 0.36 mm has a surface area of 1 mm².)

Test Method Steps

Safety Statement: APR Test and Practice documents do NOT CLAIM TO ADDRESS ALL OF THE SAFETY ISSUES, IF ANY, ASSOCIATED WITH THEIR USE. These Tests and Practices may require the use of electrically powered equipment, heated equipment and molten polymers, rotating motors and drive assemblies, hydraulic powered equipment, high pressure air, and laboratory chemicals. IT IS THE RESPONSIBILITY OF THE USER TO ESTABLISH AND FOLLOW APPROPRIATE SAFETY AND HEALTH PROCEDURES WHEN UNDERTAKING THESE TESTS AND PRACTICES THAT COMPLY WITH APPLICABLE FEDERAL, STATE AND LOCAL REGULATORY REQUIREMENTS. APR and its members accept no responsibility for any harm or damages arising from the use of or reliance of these Tests and Practice documents by any party.

Color and haze measurement

- 1) Calibrate the spectrophotometer to the manufacturer's recommendations for transmittance mode.
- 2) Measure color and haze values for five separate control plaques
 - a) Select five random plaques for evaluation.
 - b) Place a plaque in the transmittance cavity of the spectrophotometer.
 - c) Measure and record the d65 CIE L*, a*, b* color and haze % values
 - d) Repeat for each of the five plaques.
- 3) Measure the color and haze values of five plaques for each test sample.

Inclusion evaluation

This evaluation involves holding injection molded plaques in front of a diffuse white light source and visually, with no magnification, identifying any black specks or other inclusions in the plaque that are larger than 0.1 mm² in size. The TAPPI Calibrated Size Estimation Chart provides a visual standard. Ryan Quality Control provides an alternate size standard chart. A circular defect with an area of 0.1 mm² is 0.36 mm in diameter.

The test involves evaluation of 50 individual plaques for each of a control and test material; or test results can be reported per 50 plaques.

Evaluation steps:

- a) Place the plaque between your eyes and the light source. The approximate distance between plaque and eyes is 30 cm.
- b) Count any plaque with one or more black specks and/or inclusions greater than 0.1 mm².

Control Plaque Color Data

| Sample | Result | L* (d65) | a*(d65) | b*(d65) | Haze % |
|-----------------|---------|----------|---------|---------|--------|
| Control Plaques | Run 1 | | | | |
| | Run 2 | | | | |
| | Run 3 | | | | |
| | Run 4 | | | | |
| | Run 5 | | | | |
| | Average | | | | |

Test Plaque Color Data

| Sample | Result | L*(d65) | a*(d65) | b*(d65) | Haze % |
|-----------------|---------|---------|---------|---------|--------|
| Testing Plaques | Run 1 | | | | |
| | Run 2 | | | | |
| | Run 3 | | | | |
| | Run 4 | | | | |
| | Run 5 | | | | |
| | Average | | | | |

Black Speck Report

| Sample | Number of plaques with specks or inclusions | Number of Plaques Evaluated |
|-----------------|---|-----------------------------|
| Control plaques | | |
| Test plaques | | |



DOCUMENT VERSION HISTORY

| Version | Publication Date | Revision notes |
|---------|-------------------|----------------|
| 1 | November 16, 2018 | |
| | | |
| | | |
| | | |