

## PET Flake or Pellet Discoloration Test

Document Code – PET-S-02

Publication or Revision Date: November 16, 2018

### Introduction – Scope, Significance and Use

It is common in the PET industry to measure the discoloration of washed flake or pelletized product as an indicator of the presence or absence of contamination in a PET sample. Discoloration measurements can be useful in laboratory work to document the impact of package design features on PET recycling. The degree of discoloration from pure clear PET may also be a specification value used in a purchase specification.

This document presents a standard method to evaluate discoloration in flake and pellets using a color spectrophotometer in reflectance mode.

**Disclaimer:** *This document has been prepared by the Association of Plastic Recyclers as a service to the plastic industry to promote the most efficient use of the nation's plastic recycling infrastructure and to enhance the quality and quantity of recycled postconsumer plastic. The information in this document is offered without warranty of any kind, either expressed or implied, including WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, which are expressly disclaimed. APR and its members accept no responsibility for any harm or damages arising from the use of or reliance upon this information by any party. Participation in the Recognition Program is purely voluntary and does not guarantee compliance with any U.S. law or regulation or that a package or plastic article incorporating the innovation is recyclable or will be recycled.*

### Test Method Summary

The color of PET flake or pellets is evaluated in reflected light using a color spectrophotometer. One can report the absolute values employed in the CIE L\*a\*b\* Scale. One can also measure the differences between test samples and control samples. The average of five separate measurements is reported.

### Equipment Required

- Color spectrophotometer capable of testing CIE L\*a\*b\* Scale in reflectance mode with d65 light source.
- A transparent cell designed for use with the spectrophotometer that holds samples for reflectance color readings.

### Materials Required

- Samples of PET flake or pellets for evaluation.

## Test Method Steps

**Safety Statement:** *APR Test and Practice documents do NOT CLAIM TO ADDRESS ALL OF THE SAFETY ISSUES, IF ANY, ASSOCIATED WITH THEIR USE. These Tests and Practices may require the use of electrically powered equipment, heated equipment and molten polymers, rotating motors and drive assemblies, hydraulic powered equipment, high pressure air, and laboratory chemicals. IT IS THE RESPONSIBILITY OF THE USER TO ESTABLISH AND FOLLOW APPROPRIATE SAFETY AND HEALTH PROCEDURES WHEN UNDERTAKING THESE TESTS AND PRACTICES THAT COMPLY WITH APPLICABLE FEDERAL, STATE AND LOCAL REGULATORY REQUIREMENTS. APR and its members accept no responsibility for any harm or damages arising from the use of or reliance of these Tests and Practice documents by any party.*

1. Calibrate the spectrophotometer to the manufacturer's recommendations for reflectance mode.
2. Control Flake or Pellet Color Measurement steps:
  - a. Fill in the transparent reflectance cell with the sample to required level.
  - b. Place the sample cell in the spectrophotometer.
  - c. Measure the d65 CIE L\*, a\*, b\* reflected color values.
  - d. Record color data for d65 L\*, a\* and b\*.
  - e. Pour the sample contained in the cell in with the rest of the initial sample and mix it.
3. Repeat Step 2 four more times for reaching a total of 5 measurements for the control sample.
4. In the same manner, collect five color measurements for each test sample.
5. A report as shown on the next page can be used to present data.

It is common to report the difference or "delta" values between the average of the five readings between the test and control samples. There may be situations where it is valuable to report the individual measurements to assess variability within a sample. Or, to report the absolute values of a color value to make comparisons between samples.

When there are large color variations, it may be valuable to photograph samples to record and illustrate differences.

**Control Flake or Pellet Color Testing Data**

Sample	Result	L*	a*	b*
Control Flake or Pellet	Run 1			
	Run 2			
	Run 3			
	Run 4			
	Run 5			
	Average			

**Test Flake or Pellet Color Testing Data**

Sample	Result	L*	a*	B*
Testing Flake or Pellet	Run 1			
	Run 2			
	Run 3			
	Run 4			
	Run 5			
	Average			

**DOCUMENT VERSION HISTORY**

Version	Publication Date	Revision notes
1	November 16, 2018	Original Document